TOSHIBA

UM-TS03\*\*\*-E008

PROGRAMMABLE CONTROLLER PROSEC T-SERIES

# Main Menu Contents

**COMPUTER LINK FUNCTION** 

**OPERATION MANUAL** 

TOSHIBA CORPORATION

# **Safety Precautions**

This manual explains the specification and operation of Toshiba's T-series Programmable Controller's Computer Link. Read this manual carefully before using the Computer Link. Besides this manual, read the following manuals and descriptions before operation, if necessary, for your better understanding.

### **General Information**

- The T-series Programmable Controller (hereafter called T-series PLC) has been designed and manufactured for use in an industrial environment. However, the T-series PLC is not intended to be used for systems which may endanger human life. Consult Toshiba if you intend to use the Tseries PLC for a special application, such as transportation machines, medical apparatus, aviation and space systems, nuclear controls, submarine systems, etc.
- 2. The T-series PLC has been manufactured under strict quality control. However, to keep safety of overall automated system, fail-safe systems should be considered outside the T-series PLC.
- In installation, wiring, operation and maintenance of the T-series PLC, it is assumed that the users have general knowledge of industrial electric control systems. If this product is handled or operated improperly, electrical shock, fire or damage to this product could result.
- This manual has been written for users who are familiar with Programmable Controllers and industrial control equipment. Contact Toshiba if you have any questions about this manual.
- 5. Sample programs and circuits described in this guide are provided for explaining the operations and applications of the T-series PLC. You should test completely if you use them as a part of your application system.


## **Hazard Classifications**

In this manual, the following two hazard classifications are used to explain the safety precautions.

WARNING Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Even a precaution is classified as CAUTION, it may cause serious results depending on the situation. Observe all the safety precautions described on this manual.



## Note symbols

Users of this manual should pay attention to information preceded by the following symbol.



Calls the reader's attention to information considered important for full understanding of the procedures and/or operation of the equipment.

Copyright 1994 by Toshiba Corporation Tokyo, Japan

Publication number: UM-TS\*\*\*E008 1st edition Feb. 1994, 4th edition Dec. 1998

IBM is registered trademark of International Business Machines Corporation

# Contents

1. How to read this manual							
	1.1	Inside this manual	1				
	1.2	Related manual	1				
2.	Overvi	ew					
	2.1	Features	2				
	2.2	System configuration	2				
	2.3	Communication overview	3				
3.	Transr	nission mode settings	4				
	3.1	Setting procedure	4				
4.	Cable	connections	7				
	4.1	Computer Link port	7				
	4.2	One-to-one configuration	8				
	4.3	One-to-N configuration	10				
5.	Comp	uter Link protocol	13				
	5.1	Message Format	13				
	5.2	Transmission rules	14				
	5.3	Creation of checksum					
	5.4	Internal process flow	16				
6.	Comm	ands	17				
	6.1	List of commands	17				
	6.2	Computer Link Error Response (CE)	18				
	6.3	PLC Error Response (EE)	19				
	6.4	Test (TS)	22				
	6.5	PLC Status Read (ST)	23				
	6.6	PLC Error Status Read (ER)	25				
	6.7	Data Read (DR)	26				
	6.8	Data Write (DW)	28				
	6.9	Expanded File Register Read (MR)	30				
	6.10	Expanded File Register Write (MW)	31				
	6.11	System Information 1 Read (SR)	32				
	6.12	System Information 2 Read (S2)	34				

6.13	Diagnostic Message Read (TR)	37
6.14	Clock-calendar Read (RT)	39
6.15	Clock-calendar Write (WT)	40
6.16	PLC Control (EC)	41
6.17	System Information Block Read (BR)	43
6.18	Program Block Read (RB)	45
6.19	Comment Block Read (CR)	47
6.20	System Information Block Write (BW)	49
6.21	Program Block Write (WB)	50
6.22	Comment Block Write (CW)	51
7. Samp	le communication programs	52
-		52
	Simple send/receive test	
7.1		52
7.1 7.2	Simple send/receive test	52 53
7.1 7.2 7.3	Simple send/receive test Send/receive test with sum check	52 53 54
7.1 7.2 7.3	Simple send/receive test Send/receive test with sum check Program up-loading	52 53 54
7.1 7.2 7.3 7.4	Simple send/receive test Send/receive test with sum check Program up-loading	52 53 54 55
7.1 7.2 7.3 7.4	Simple send/receive test Send/receive test with sum check Program up-loading Program down-loading	52 53 54 55 56
7.1 7.2 7.3 7.4 Appendia A.1	Simple send/receive test	52 53 54 55 56 56

#### 1. How to read this manual

This section outlines this manual to provide a helpful head start before you begin.

1.1 Inside this manual This manual provides all the information you need to wire, set-up and operate the T-series Programmable Controller's Computer Link function. In this manual, the T-series Programmable Controllers are referred as PLC. This manual is divided into seven main sections and appendices: 1. How to read this manual (this section) 2. Overview introduces the features and overview of the Computer Link function. 3. Transmission made settings describes how to set the transmission mode of the T-series Programmable Controllers. 4. Cable connections describes how to connect between the host computer and T-series Programmable Controllers. 5. Computer Link protocol gives the general information for the Computer Link protocol. 6. Commands explains the function and message format of each command in detail. 7. Sample communication programs provides some sample programs for the host computer. Appendices contain the specifications of the Computer Link interface and the description of the RS485/RS232C converter which can be used with the Computer Link function. 1.2 Related manual The following related manuals are available for the T-series Programmable Controllers. T1/T1S User's Manual - Basic Hardware and Function (UM-TS01\*\*\*-E001) T1/T1S User's Manual - Expansion I/O (UM-TS01\*\*\*-E002) T1/T1S User's Manual - Communication Function (UM-TS01\*\*\*-E003) T2E User's Manual (UM-TS02E\*\*\*-E001) T2N User's Manual (UM-TS02N\*\*\*-E001) T2E/T2N User's Manual - Communication Function (UM-TS02E\*\*\*-E003) T3 User's Manual - Hardware (UM-TS03\*\*\*-E002) T3 User's Manual - Functions (UM-TS03\*\*\*-E003) T3H User's Manual (UM-TS03\*\*\*-E032) T-series Instruction Set (UM-TS03\*\*\*-E004) T-PDS (DOS) Basic Operation Manual (UM-TS03\*\*\*-E006)

T-PDS (DOS) Basic Operation Manual (UM-TS03<sup>ma-</sup>E006)

T-PDS (DOS) Command Reference Manual (UM-TS03\*\*\*-E007) T-PDS (DOS) Ver. 2.1 Expanded Functions (UM-TS03\*\*\*-E028)

T-PDS for Windows Operation Manual (UM-TS03\*\*\*-E038)

#### 2. Overview

This section introduces the features and overview of the Computer Link function.

2.1


Features Using the Computer Link function, you can connect a host computer to one or more PLC and execute the following functions.

- Reading data (register/device value) from PLC
- Writing data (register/device value) into PLC
- Monitoring PLC operation status (RUN/HALT/ERROR)
- Controlling PLC operation mode (RUN/HALT)
- Up-loading PLC program
- Down-loading PLC program
- 2.2

System configuration

With the Computer Link system, up to 32 PLCs can be linked to a host computer, through standard RS485 interface. With this system, the maximum transmission distance (total) is 1 km.


If the host computer uses an RS232C interface, the RS485/RS232C converter (ADP-6237B) can be used to adapt.



2.3 Communication overview

In the Computer Link system, each PLC waits for requests issued by the host computer. When a request is generated, each PLC checks the station number of the request. The PLC with the matching station number processes the request and returns the response, while the other PLCs continue to stand by. This is why each PLC must have a unique station number. Otherwise more than one PLC may attempt to process the request, resulting in faulty response.

The following diagram illustrates the processing sequence executed when a request to station number 3 is issued:



- **1** Request is sent from the host computer to PLCs (request to station #3 in this example).
- **2** Request is interpreted and processed in the PLC which has the same station number as request (station #3 PLC in this example).
- **3** Processing result is returned as response to the host computer.

### 3. Transmission mode settings

The transmission mode settings are stored in the PLC memory. This section describes how to set the transmission mode of the PLC.

3.1 Setting procedure PLC's transmission mode is set by using T-series PLC Programming software (T-PDS). The transmission mode of PLCs and the host computer must be matched.



Refer to T-PDS Operation Manual for detailed explanation for the T-PDS operation.

- (1) Connect the PLC and the T-PDS through PLC's programmer port by using optional cable.
- (2) Start up the T-PDS.
- (3) Change the T-PDS to Online mode. The screen shown below is T-PDS's main menu screen.

***	T-PDS MODE MENU ***								
S: System Information	T: Load/Save/Compare								
P: Program	0: Setup Options								
M: Data Monitor	L: Online/Offline								
C: Reg/dev comments	W: Password								
D: Documentation	B: Block Edit								
U: Usage Map	Q: Quit								
Select hu using [^]	or [↓] keys and press [Enter] key								
PLOHALT PROG	Control								
F1 F2 F3 F4	F5 F6 F7 F8 F9 F10								

(4) If your PLC is in RUN mode, turn the PLC to HALT mode to enable to edit it's system parameters.

<system parameters=""></system>										
1. Program ID	[	1	8.	Error St	atus					
2. System Comments [		]								
3. Memory Capacity	10kS	/ 4k₩								
4. Steps Used	I	9	9.	Diagnost	ic Messa	ige				
5. PLC Type	T2E									
6. PLC OS Version	Ver.	1.01	10.	Date & 1		س دادا )				
7. T-PDS Version	Ver.	2.1e	[98-12-15] (yy-mm-dd) [22:52:05] (hh:mm:ss)							
PLCHALT PROG SysPar						C	Coursel			
Edit Next DiagRst						LONTROI	Cancel			
F1 F2 F3	F4	F5	F6	F7	F8	F9	F10			

(5) Select "S:System Information" from the main menu, then select "P: System Parameters" form the System Information sub-menu.

(6) Press F1 (Edit) then press F2 (Next) to move into the Computer Link transmission mode setting.

<system parameters=""></system>	
11. Program Size Setting [11]] IkSteps	14. Scan Time Setting [ ]x10mS
12. Sampling Buffer Size [ 8]kWords	15. Subprogram Execution Time $1\sim$ 100 mS [ ]mS
13. Retentive Memory Area $RW000 \sim [ ]$ $T000 \sim [ ]$ $C000 \sim [ ]$ $D0000 \sim [ ]$ 14. 10mS Timer $T000 \sim [ 63]$ 15. Start Mode <u>Stanby</u> Auto	<pre>16. Timer Interrupt Interval 2 ~ 1000 mS [ ]mS 17. Computer Link Settings Station No. [ 1] Baud rate [ 9600]BPS Parity Non <u>Odd</u> Even Data length [8]Bit Stop bit <u>1</u> 2</pre>
PLCHALT PROG SysPar Edit Next Write F1 F2 F3 F4 F5	AllClr Clear Control Cancel F6 F7 F8 F9 F10

(7) Move cursor to "17. Computer link Settings", and set Station No, Baud rate, Parity, Data length and Stop bit.

Station No.:	1 to 32
Baud rate:	300, 1200, 2400, 4800, 9600 or 19200 bps
Parity:	Non, odd or even
Data length:	7 or 8 bits
Stop bit:	1 or 2 bits
-	



If you will use the T-PDS through the Computer Link port, Baud rate, Data length and Stop bit should be set as follows. Because these settings are fixed on the T-PDS. Baud rate: 9600 bps Data length: 8 bits Stop bit: 1 bit

(8) When necessary settings are finished, press F3 (Write) to write the setting information into the PLC. The following confirmation message window will appear on the screen.

<system parameters=""></system>	
11. Program Size Setting [10]kSteps	14. Scan Time Setting [ ]x10mS
12. Sampling Buffer Size [ 8]kWords	15. Subprogram Execution Time $1\sim$ 100 mS [ ]mS
13. Retentive Memory Area $ ext{RW000} \sim  ext{I}  ext{I}  ext{T000} \sim  ext{I}  ext{I}  ext{T000} \sim  ext{I}  ext{I}  ext{L000}  ext{L}  ext{L} $	16. Timer Interrupt Interval 2 $\sim$ 1000 mS [ ]mS 17. Computer Link Settings Station No. [ 5]
14. 10mS Timer $ extsf{T000} \sim  extsf{E}$ 63] 15. Start Mode $ extsf{Stanby}$ Auto	Baud rate [96001BPS Parity <u>Non</u> Odd Even Data length [81Bit Stop bit <u>1</u> 2
Execute ? Y: Yes N: No	
PLCHALT PROG SysPar Edit Write	Cancel
F1 F2 F3 F4 F5	F6 F7 F8 F9 F10

(9) Confirm each setting and press [Enter] key. Now, the transmission mode settings have been completed.

### 4. Cable connections

This section describes how to connect between a host computer and PLCs. The details of the Computer Link port provided on the PLC is described first, then cable connections depending on the configurations are explained.

4.1 Computer Link port The Computer Link uses 4-wire RS485 interface. A standard 15-pin female connector is provided on the PLC's front panel as the Computer Link port. The following table shows the pin assignment of this Computer Link port.

Pin No.	Signal name	Description	Signal direction		
1	FG	Protective ground	PLC — Host		
7	SG	Signal ground	PLC — Host		
3	ТХА	Transmitted data			
11	ТХВ	Transmitted data	$PLC \rightarrow Host$		
2	RXA	Received data			
10	RXB	Received data	$PLC \leftarrow Host$		
5	RTSA	Pequest to cond	PLC $\rightarrow$ Host		
13	RTSB	Request to send			
4	CTSA	Clear to send			
12	CTSB		$PLC \leftarrow Host$		




- (1) Refer to the T2E/T2N User's Manual -Communication Function- for the pin assignment of the T2E and T2N computer link port.
- (2) Refer to the T1/T1S User's Manual -Communication Function- for the pin assignment of the T1 and T1S computer link port.


One-to-one configuration

When one PLC is connected to a host computer, the cable connections should be as follows.

RS485 direct connections:



- (1) Connect R (1/2 W-120 ohm) between RXA and RXB on the PLC side.
- (2) If the host computer has built-in termination resistors, set to connect the built-in resistors.
- Otherwise, connect R (1/2 W-120 ohm) between RD (A) and RD (B) externally.
- (3) For noise immunity, use shielded twisted-pair cable. The cable shield should be connected to FG (pin 1) or ground of PLC side.
- (4) If CTS (A/B), RTS (A/B) are not used, connect them each other on the PLC side as follows.
  - CTSA RTSA CTSB – RTSB



Using RS485/R232C converter (ADP-6237B):

- (1) Connect R(1/2 W-120 ohm) between RXA and RXB on the PLC side.
- (2) Connect RXA and TERM on the converter (ADP-6237B) side to use built-in termination resistor.
- (3) For noise immunity, use shielded twisted-pair cable. The cable shield should be connected to FG (pin 1) or ground of PLC side.




For details of the RS485/RS232C converter (ADP-6237B), see Appendix A.2.

One-to-N configuration


When two or more PLCs are connected to a host computer, the cable connections should be as follows. (Up to 32 PLCs can be connected on a system)

The transmission line configuration of the Computer Link system is party line. Therefore only two terminations are allowed.




Termination resistors (1/2W-220 ohm) should be connected between TXA and TXB, and RXA and RXB, as each end of the line (termination stations).

RS485 direct connection:



- (1) Connect R (1/2 W-220 ohm) between TXA and TXB (or SD (A) and SD (B)), and between RXA and RXB (or RD (A) and RD (B)) at each termination station.
- (2) For noise immunity, use shielded twisted-pair cable. The cable shield should be connected to FG (pin 1) or ground at one end only.
- (3) Connect CTSA and RTSA, CTSB and RTSB on each PLC.
- (4) Use terminal blocks to branch off the line. The branch should not exceed 3m cable length form the terminal block to the PLC or the host computer.



Using RS485/R232C converter (ADP-6237B):

- (1) Connect R (1/2 W-220 ohm) between TXA and TXB (or SD (A) and SD (B)), and between RXA and RXB (or RD (A) and RD (B)) at each termination station.
- (2) For noise immunity, use shielded twisted-pair cable. The cable shield should be connected to FG (pin 1) or ground at one end only.
- (3) Connect CTSA and RTSA, CTSB and RTSB on each PLC.
- (4) Use terminal blocks to branch off the line. The branch should not exceed 3 m cable length form the terminal block to the PLC or the host computer.

NOTE ▼∆▼


- (1) Refer to Section 4.2 for RS232C side connections.
- (2) For details of the RS485/RS232C converter (ADP-6237B), see Appendix A.2.

### 5. Computer Link Protocol

This section gives the general information for the Computer Link protocol.

5.1

Message format The T-series PLC uses the following message format.



#### Text contents

- (----- Start code (H28) 1 byte
- A ----- Format identification code (H41) byte
- ADR --- Station number 2 bytes
  - 01 (H3031) through 32 (H3332)
- CMD --- Command 2 bytes
- DATA -- Data field depending on the command
- & ----- Checksum delimiter (H26) 1 byte
- SUM --- Checksum 2 bytes
  - ASCII code of the lowest one byte of the sum obtained by adding from the start code "(" to the checksum delimiter "&"
- ) ----- End code (H29) 1 byte
- ; ----- End code (H3B) 1 byte
- in case of halfway of entire data
- CR----- Carriage return code (H0D) 1 byte



(1) The maximum message text length is limited to 255 bytes.


(2) The Checksum delimiter and Checksum data of request text can be omitted.

Transmission rules

The following transmission rules apply to the Computer Link communication.

- (1) The PLC is always waiting for a request command from the host computer. The PLC will not transmit any text without a request.
- (2) All space codes (H20) are ignored.

If space codes (H20) are included in the request text issued from the host computer, they are ignored. However, the space codes are included in checksum calculation.




(3) Checksum can be omitted in the request text issued from the host computer.

(4) Checksum is always attached to the response text issued from the PLC.

#### Request text

ſ	(	А	0	1	Т	S	5	5	)	CR
L	•								,	

#### Response text




Response text always includes Checksum and the delimiter code (&).

- (5) 7 or 8- bit ASCII is used for all request/response text.
- (6) The PLC ignores all the data received before the start code "(".
- (7) Reception is completed only after the end code, ")" or ";", and CR have been received. If the end code without CR, or vice versa, is received, it becomes communication error.
- (8) The PLC checks the request text reception time. If the reception time, from the start code "(" to CR, exceeds the time limit, it becomes no response form the PLC. The following table shows the time limit in each baud rate.

Band rate	Time limit
300 bps	30 sec.
1200 bps	8 sec.
2400 bps	4 sec.
4800 bps	2 sec.
9600 bps	1 sec.
19200 bps	0.5 sec.

(9) After one PLC finished to send the response, other PLCs cannot send any data during the inhibited time. The host computer should send the next request after the inhibited time from the previous response reception. The following table shows the inhibited time in each baud rate.

Band rate	Inhibited time
300 bps	40 msec.
1200 bps	20 msec.
2400 bps	10 msec.
4800 bps	10 msec.
9600 bps	10 msec.
19200 bps	10 msec.




Creation of checksum

Checksum is the ASCII code of the lower two digits of the sum obtained by adding the hexadecimal data from the start code "(" to the checksum delimiter "&".

(	А	0	1	Т	S	5	5	&	0	1	)	CR
									-1	· · · ·	-	
		"("	=	H28	3							
		"A"	' =	H4′	1							
		"0"	=	H3(	)							
		"1"	=	H3′	1							
		"T"	=	H54	1							
		"S"	' =	H53	3							
		"5"	=	H3	5							
		"5"	=	H3	5							
		"&"	' =	H26	5							
			Н	201		<		Sur	n			

5.4 Internal process flow

The following diagram illustrates the PLC internal process flow for the Computer Link function.



## 6. Commands

# 6.1 List of Commands The following Computer Link commands are available.

Request command	Function name	Description	Response command	Note
	Computer Link Error Response	Format error has been detected	CE	Response only
	PLC Error Response	Request command has been rejected by PLC	EE	Response only
TS	Test	Loop back test	TS	
ST	PLC Status Read	Reads PLC status	ST	
ER	PLC Error Status Read	Reads PLC error status	ER	
DR	Data Read	Reads registers/devices data	DR	
DW	Data Write	Writes registers/devices data	ST	
MR	Expanded File Register Read	Reads expanded file register data (from IC memory card)	MR	T3H only
MW	Expanded File Register Write	Writes expanded file register data (into IC memory card)	ST	T3H only
SR	System Information 1 Read	Reads PLC system information 1	SR	
S2	System Information 2 Read	Reads PLC system information 2	S2	
TR	Diagnostic Message Read	Reads user-defined error information	TR	
RT	Clock-calendar Read	Read clock-calendar data	RT	
WT	Clock-calendar Write	Writes clock-calendar data	ST	
EC	PLC Control	Changes PLC operation mode	ST	
BR	System Information Block Read	Reads system information block- by-block	BR	
RB	Program Block Read	Reads program block-by-block	RB	
CR	Comment Block Read	Reads comments block-by-block	CR	T3/T3H only
BW	System Information Block Write	Write system information block- by-block	ST	
WB	Program Block Write	Writes program block-by-block	ST	
CW	Comment Block Write	Write comments block-by-block	ST	T3/T3H only




In the following command explanations, execution examples are the results of using a sample program described in Section 7.2

Computer Link Error Response (CE) When the PLC detects a parity error, checksum error, format error, etc., the PLC will respond "CE" with the error content.

Request text - any command

Response text



Error codes as listed below

Error	Error name	Description						
01	Command error	Received command is illegal						
02	Format error	Received next format is illegal						
03	Checksum error	Checksum mismatch is detected						

Execution examples Example 1)

INPUT DATA = (A01SS) SEND DATA = (A01SS&96) RECEIVE DATA = (A01CE01&D9)

Command error (01) ... Illegal command (SS)

Example 2)


INPUT DATA = (A01DRRW100,2YW100,3) SEND DATA = (A01DRRW100,2YW100,3&BE) RECEIVE DATA = (A01CE02&DA)

Format error (02) ... Missing comma between starting register address and number of registers

PLC Error Response (EE) When the PLC receives an unacceptable command, the PLC will respond "EE" with the error content.

Request text - any command

#### Response text



Error	Error name	Description	EE	ER
0010	Power ON	PLC power on		✓
0011	Power OFF	PLC power off		$\checkmark$
0012	Expansion unit power failure	Expansion unit power failure has been detected	√	~
0013	Momentary power interruption	Momentary power interruption has been detected		~
0014	Momentary power interruption resume	Power has been resumed from momentary interruption		~
0020	RAM check error	RAM error has been detected		✓
0021	Program BCC error	Program BCC error has been detected		✓
0022	Battery voltage drop	Battery voltage drop has been detected		✓
0023	EEPROM BCC error	BCC error has been detected in built-in EEPROM		~
0024	EEPROM write error	Data could not be written into EEPROM normally		~
0026	EEPROM write times warning	EEPROM write operation has exceeded 100,000 times		~
0030	System RAM error	System RAM error has been detected		✓
0031	System ROM BCC error	BCC error has been detected in system ROM		~
0033	Clock-calendar check error	Abnormality has been detected in clock- calendar		~
0034	System illegal interrupt	Illegal interrupt has occurred		✓
0035	Watch dog timer error	Watch dog timer error has occurred		~
0040	I/O bus error	I/O bus error has been detected	$\checkmark$	✓
0041	I/O mismatch	Mismatching of mounting I/O and registered I/O has been detected	√	~
0042	I/O no answer	No response from registered I/O	$\checkmark$	~

Error	Error name	Description	EE	ER
0043	I/O parity error	I/O parity error has been detected	~	~
0044	I/O illegal interrupt	I/O illegal interrupt has occurred		~
0045	I/O allocation duplicated	Duplicate I/O register allocation has been detected	~	~
0046	I/O allocation address over	Excess I/O register allocation has been detected	~	~
0051	Communication busy	PLC is busy in processing for other peripheral communications	~	
0052	Format error	Received text format is illegal	$\checkmark$	
0060	LP function check error	LP(language processor) function check error has been detected		~
0063	LP execution time out	LP (language processor) error has been detected		~
0064	Scan time over	Scan time has exceeded 200 ms		✓
0080	No END instruction	END instruction has not been programmed	~	✓
0081	Illegal pair instructions	Illegal combination of pair instructions has been detected	~	~
0082	Illegal operand	Illegal operand has been detected	✓	✓
0083	Abnormal program	Address control table inconsistency	✓	✓
0084	Jump destination error	Jump destination error has been detected	✓	✓
0086	No subroutine entry	Subroutine entry instruction has not been programmed	~	~
0087	No subroutine return	Subroutine return instruction has not been programmed	~	~
0088	Subroutine nesting over	Excess (max 6) subroutine nesting has been detected	~	~
0089	FOR-NEXT loop nesting over	Excess (max 6) FOR-NEXT loop nesting has been detected	~	~
0090	SFC step number error	Duplicate SFC step number has been detected	~	~
0091	SFC macro number duplicated	Duplicate SFC macro number has been detected	~	~
0092	No SFC macro entry	SFC macro entry has not been found	✓	~
0094	SFC jump label duplicated	Duplicate SFC jump label has been detected	~	~
0095	No SFC jump label	SFC jump label has not been found	~	~
0096	SFC program number duplicated	Duplicate SFC program number has been detected	~	~
0097	SFC program abnormal	Illegal combination of SFC initial and end steps has been detected	~	~
0098	Unsupported function instruction	Unsupported function instruction has been detected	~	~

Error	Error name	Description	EE	ER
0106	Password protect	Requested operation is protected by password	√	
0108	Comment space full	Comment memory is insufficient for the requested command	√	
0109	Memory type error	Memory capacity type mismatch	$\checkmark$	
0110	Illegal instruction	Illegal instruction has been detected	$\checkmark$	✓
0111	Register address over	Excess register address range has been programmed	√	~
0112	Boundary error	Boundary error has occurred		✓
0113	Memory full	Program memory is insufficient for the requested command	√	
0114	Mode mismatch	Received command is invalid in current PLC operation mode	√	
0115	Register address/size error	Specified register range exceeds the limit	√	
0117	Memory protect	Writing operation is protected (P-RUN)	✓	
0121	Jump label/subroutine entry duplicated	Duplicate jump label or subroutine entry has been detected	√	~
0128	No IC card error	IC memory card is not installed or not allocated for PU slot (MMR setting)		~
0129	IC memory card BCC error	BCC error has been detected in the IC memory card		~
0132	IC card type error	IC memory card is used for Program storage		~
0133	IC memory card capacity mismatch	Memory capacity type mismatch between IC memory card and PLC		~
0134	IC card write-protect error	IC memory card is set as write-protect		~

• Errors marked ✓ in EE column are responded with the PLC Error Response (EE).

• Errors marked ✓ in ER column are read out by the PLC Error Status Read command (ER).


Execution examples Example 1)

INPUT DATA	=	(A01EC02)
SEND DATA	=	(A01EC02&DA)
RECEIVE DATA	=	(A01EE0114&40)

Mode mismatch (0114) ... PLC control command (RUN command) is issued under RUN mode

Test (TS) This command tests the communication between the host computer and the PLC. When the PLC receives the Test command (TS), it returns the same text to the host computer.

Request text



1		2	3	4	5	6	7					
(	(	А	AD	DR	Т	S		Test data	&	SUM	)	CR

"CE" or "EE" is returned when communication error has occurred.

- The maximum size of the Test data field is 244 bytes.
- Any ASCII code, except for the following characters, can be used.
  - "(" H28 "&" H26 — Error (CE) is returned ")" H29 CR H0D \_\_\_\_\_ Ignored
- " " H20 Ignored

Execution examples Example 1)

INPUT DATA = (A01TS123456789) SEND DATA = (A01TS123456789&74) RECEIVE DATA = (A01TS123456789&74)

#### Example 2)


INPUT DATA	=	(A01TS	12345)
SEND DATA	=	(A01TS	12345&16)
RECEIVE DATA	=	(A01TS1234	5&96)

Space codes in the Test data are ignored

#### 6.5 PLC Status Read (ST)

This command reads the PLC operation status.

Request text




Response text

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
(	А	AD	DR	S	Т		Sta	itus		&	SUM		)	CR

"CE" or "EE" is returned when communication error has occurred.

• The Status field shows the PLC operation status as follows.



## Example 2)

INPUT DATA SEND DATA RECEIVE DATA	= (A01ST) = (A01ST&97) = (A01ST0102&5A)
7     8     9       0     1     0	<u>10</u> 2
	PLC mode = RUN Memory protect (h=1)
Example 3)	
INPUT DATA SEND DATA RECEIVE DATA	<pre>= (A01ST) = (A01ST&amp;97) = (A01ST8004&amp;63)</pre>
7     8     9       8     0     0	<u>10</u> 4
	PLC mode = HOLD Battery alarm (a=1)

PLC Error Status Read (ER)

If an error occurs in the PLC, this command can be used to read the error cause and determine why the PLC shut down.

Request text

( A ADR E R & SUM ) CR	1										
	(	А	AD	DR	Е	R	&	SL	JM	)	CR

← → Can be omitted

Response text

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
(	А	AD	DR	Е	R		Er	ror		&	SL	JM	)	CR

"CE" or "EE" is returned when communication error occurs

The Error field shows the latest error status stored in the PLC's event history table.
Refer to Section 6.3 PLC Error Response (EE) for the contents of Error.

Execution examples Example 1)

INPUT DATA	=	(A01ER)
SEND DATA	=	(A01ER&87)
RECEIVE DATA	=	(A01ER0080&4F)


Error code = 0080 ... No END instruction



Even if the error has been reset, "ER" command reads the latest error status stored in PLC's event history table.

Data Read (DR)

This command is used to read the data of registers and/or devices consecutively. Multiple types of registers/devices can be specified at a time.




"CE" or "EE" is returned when communication error occurs

- This command reads the data of specified number of registers/devices starting with specified address.
- Multiple types of registers/devices can be specified at a time.
- Total up to 32 register/device data can be read at a time.
- $\bullet$  Upper 0 can be omitted in the starting register/device and the number fields. (E.g., R0009  $\rightarrow$  R9, 05  $\rightarrow$  5)
- If the content of a number field is 1, the number field can be omitted.
- The starting register/device and the number fields are separated by "," (comma).
- In the response text, the data are packed in the specified order.
- Each data is expressed in 4 digits hexadecimal format. For a device, "0000" and "0001" represent OFF and ON respectively.

	<ul> <li>NOTE</li> <li>▼△▼</li> <li>(1) In case of Timer/Counter register read, the device data (2 bytes each) corresponding to the register are added. If the Timer/Counter has been time-up/count-up, the device data is "01". Otherwise, it is "00".</li> </ul>										
	(2) The types of register/device which can be specified are as follows.										
	Register: XW, YW, SW, LW, RW, W, T, C, D and F (IW, OW, I, J and K cannot be specified)										
	Device: X, Y, S, L, R and Z (T., C., I and O cannot be specified)										
Execution examples	Example 1)										
	INPUT DATA = (A01DRRW1,3) SEND DATA = (A01DRRW1,3&BF) RECEIVE DATA = (A01DR1EB922F122A8&2F)										
	Three registers starting with RW001 RW001 = H1EB9, RW002 = H22F1, RW003 = H22A8										
	Example 2)										
	INPUT DATA = (A01DRRW4) SEND DATA = (A01DRRW4&63) RECEIVE DATA = (A01DR004E&5F)										
	RW004 (Number field omitted) RW004=H004E										
	Example 3)										
	INPUT DATA = (A01DRYW1,3,R50,5) SEND DATA = (A01DRYW1,3,R50,5&0A) RECEIVE DATA = (A01DR0000001B8AAA0001000100000000000000000000										
	YW001 to YW003 and R0050 to R0054 YW001 = H0000, YW002 = H001B, YW003 = H8AAA R0050 = ON, R0051 = ON, R0052 = OFF, R0053 = OFF, R0054 = ON										
	Example 4)										
	INPUT DATA = (A01DRC0) SEND DATA = (A01DRC0&F9) RECEIVE DATA = (A01DR000301&AA)										
	C000 (Counter register) C000 = 0003 present value C.000 = 01 (on) count - up										

Data Write (DW)

This command is used to write the data into the PLC's registers and/or devices consecutively. Multiple types of registers/devices can be specified at a time.



"CE" or "EE" is returned when communication error occurs

- This command writes the data into the specified number of registers/devices starting with specified address.
- Multiple types of registers/devices can be specified at a time.
- Total up to 32 register/device data can be written at a time.
- $\bullet$  Upper 0 can be omitted in the starting register/device and the number fields. (E.g., R0009  $\to$  R9, 05  $\to$  5)
- The starting register/device, the number and each data fields are separated by "," (comma).
- Each data is expressed in 4 digits hexadecimal format. For a device, "0000" and "0001" represent OFF and ON respectively.
- When the processing is completed normally, the PLC Status Read (ST) response is returned.



- (1) In case of Timer/Counter register write, the device data (2 bytes each) corresponding to the register should be added. If the Timer/Counter device is set to ON, it should be "01". Otherwise, it should be "00".
- (2) The types of register/device which can be specified are as follows.

Register: XW, YW, SW, LW, RW, W, T, C, D and F (IW, OW, I, J and K cannot be specified)

Device: X, Y, S, L, R and Z (T., C., I and O cannot be specified)

Execution examples Example 1)

INPUT DATA = (A01DWRW1,3,FFFF,5A5A,0011)
SEND DATA = (A01DWRW1,3,FFFF,5A5A,0011&0E)
RECEIVE DATA = (A01ST0004&5B)

Writes HFFFF, H5A5A and H0011 into RW001, RW002 and RW003 respectively

INPUT DATA	=	(A01DRRW1,3)
SEND DATA	=	(A01DRRW1,3&BF)
RECEIVE DATA	=	(A01DRFFFF5A5A0011&4C)

Confirmation by DR command

Example 2)

```
INPUT DATA =
(A01DWD100,2,FFFF,EFFF,R20,5,0001,0001,0000,0000,0001)
SEND DATA =
(A01DWD100,2,FFFF,EFFF,R20,5,0001,0001,0000,0000,0001&25)
RECEIVE DATA = (A01ST0004&5B)
```

Writes HFFFF and HEFFF into D100 and D101, writes ON, ON, OFF, OFF, ON into R0020 to R0024 respectively

INPUT DATA = (A01DRR20,5) SEND DATA = (A01DRR20,5&9B) RECEIVE DATA = (A01DR000100000000001&49)

Confirmation by DR command (R0020 to R0024)

## 6.Commands

NOTE ▼∕∆▼

### 6.9

Expanded file register data read (MR) This command is used to read the PLC's expanded file register data store in the IC memory card.

There are two types of data storage format for the IC memory card. They are 8 k words per bank and 64 k words per bank. (Refer to XFER instruction) Note that the computer link commands for these formats are slightly different.

#### Request text

T3H version 1.1 or later only

1	2	3	4	5	6	7	8	9	10	11	12	13	14 15	16	17 18	19	20 21	22	23
(	А	AD	DR	Μ	R	S	tart	ing	reg	iste	er	,	Bank	,	Ν	&	Sum	)	CR
					•	<			K		$\rightarrow$	•	$\langle \gamma \rangle$	;	≶∕→		$\wedge$		
	Can be shortened Can be omitted																		
	Starting register:																		
	For 8 k words per bankF0000 to F8191 $\leftarrow$ Upper case F																		
F	For 64 k words per bankf0000 to f65535 (bank 1) f0000 to f57343 (bank 2) $\bigcirc$ Lower case f																		

Bank: For 8 k words per bank-----1 to 15 For 64 k words per bank ----1 to 2

N: Number of registers to be read ---- 1 to 61 (61 words max.)

Response text

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
(	А	AD	DR	Μ	R	[	Data	a #'	1	[	Data	a #2	2	

 n-5 n-4 n-3 n-2 n-1 n													
Data #N-1	Data #N	&	Sum	)	CR								

"CE" or "EE" is returned when communication error occurs

#### 6.10 Expanded file register

data Write (MW)

This command is used to write the PLC's expanded file register data stored in IC memory card.

There are two types of data storage format for the IC memory card. They are 8 k words per bank and 64 k words per bank. (Refer to XFER instruction) Note that the computer link commands for these formats are slightly different.



T3H version 1.1 or later only

1	2	34	5	6	7	8	9	10	11	12	13	14	15	16	17 1	8	19	20 21	22	23
(	А	ADR	М	W	S	tarti	ing	reg	gist	er	,	Ba	nk	,	Ν		,	Dat	a #1	
	Can be shortened																			
	n-5 n-4 n-3 n-2 n-1 n														n					
	, Data #N-1 , Data #N & Sum ) CR													CR						
	Can be shortened Can be omitted																			

Starting register:

Request text

For 8 k words per bank	F0000 to F8191 $\leftarrow$ Upper case F
For 64 k words per bank	f0000 to f65535 (bank 1) f0000 to f57343 (bank 2)
	f0000 to f57343 (bank 2) $\downarrow \leftarrow$ Lower case r

Bank: For 8 k words per bank-----1 to 15 For 64 k words per bank ----1 to 2

N: Number of registers to be written---1 to 46 (see Note)

Response text

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
(	А	A	DR	S	Т		Sta	atus		&	Su	um	)	CR


"CE" or "EE" is returned when communication error occurs




In the MW command, data field is also variable length. Therefore if some of the writing data are designated with less than 4 bytes, more than 46 registers can be specified by one command. In this case, it is limited by total text length (max. 255 bytes).

System Information 1 Read (SR) This command is used to read the PLC's system information page 1 (Used steps, Program I.D., Program comment, Memory type, PLC type and PLC OS version.)

Request text





75	76	77	78	79
&	SL	JM	)	CR


"CE" or "EE" is returned when communication error occurs

• Used steps: Steps of user program used (Decimal format)

7	8	9	10	11	12	_
0	0	0	2	5	6	$\leftarrow$ 256 steps

- Program I.D.: Registered name of user program
- Program comment: Registered comment for user program

• Memory type: Memory capacity type of the PLC



- PLC type: PLC model
- PLC OS version: PLC system version number



For detailed meanings of each item, see your PLC's User's Manual.

Execution examples Example 1)

INPUT DATA = (A01SR)
SEND DATA = (A01SR&95)
RECEIVE DATA =
(A01SR000114SAMPLE001 T3 Sample Program 4/14/93 32 8 T3 Ver. 1.31
&B8)


Used steps = 114 steps Program I.D. = SAMPLE001 Program comment = T3 Sample Program 4/14/93 Memory type = 32 k steps/8 k words PLC type = T3 PLC OS version = Ver. 1.31

System Information 2

Read (S2)

This command is used to read the PLC's system information page 2 (Program size, Sampling buffer size, Retentive memory area, Constant scan interval, Subprogram execution time limit, Timer interrupt interval and Computer Link transmission mode settings).

#### Request text



#### Response text

_	1	2	3	4	5	6	7	8	9	10			
	(	А	AD	DR	S	2	P. s	size	S.b	uffer			
			•			•	•						
_	11	12	13	14	15	16	17	18	19	20	21	22	
	Re	etentiv	/e (R\	N)	F	Retent	tive (T	)	F	Retent	ive (C	;)	
	00	24	25	26	27	28	29	30	31	32	33	34	
	23	24	25	20	21	20	29	30	51	52	55	57	
ſ	-		ive (D		_	onsta				ub. tir			
[	-				_					-			]
	-				_					-			]
[	F 35	Retent	ive (C	)) 38	C 39	onsta	nt sca	an	S 43	ub. tir	ne lin	nit	]
[	F 35	Retent	ive (D	)) 38	C 39	onsta 40	nt sca	an	S 43	ub. tir 44	ne lin	nit	]
[	F 35	Retent	ive (D	)) 38	C 39	onsta 40	nt sca	an	S 43	ub. tir 44	ne lin	nit	57

CR

"CE" or "EE" is returned when communication error occurs


• P. size: Program size setting (Decimal)

$$\begin{array}{ccc}
7 & 8 \\
\hline
1 & 6 \\
\end{array} \leftarrow 16 \text{ k steps}
\end{array}$$

• S. buffer: Sampling buffer size setting (Decimal)

$$\begin{array}{c|c}9 & 10\\\hline 0 & 8\\\hline \leftarrow 8 \text{ k words}\end{array}$$

• Retentive: Retentive memory area settings for RW, T, C and D (Decimal)



• Constant scan: Constant scan interval setting (Decimal)

27	28	29	30	
0	1	0	0	$\leftarrow$ 100 msec.
				"0000" is floating scan

• Sub. time limit: Time limit for subprogram execution (Decimal)

31	32	33	34	
0	0	0	8	$\leftarrow$ 8 msec

• Timer interrupt: Timer interrupt interval setting (Decimal)


35	36	37	38	
0	5	0	0	$\leftarrow$ 500 msec.
				"0000" is no execution

• Stn No.: Station number setting for Computer Link (Decimal)


• Baud rate: Baud rate setting for Computer Link (Decimal)

41 42 43 44 45 46  
9 6 0 0 
$$\leftarrow$$
 9600 bps  
Space codes (H20) are inserted in


• Parity: Parity setting for Computer Link



• Data bit: Data bit length setting for Computer Link



• Stop bit: Stop bit length setting for Computer Link






For detailed meanings of each item, see your PLC's User's Manual.

```
Execution examples Example 1)
```


```
INPUT DATA = (A01S2)
SEND DATA = (A01S2&75)
RECEIVE DATA =
(A01S23202012700310031051102000000100001 9600000801&31)
```

Program size setting = 32 k steps Sampling buffer size setting = 2 k words Retentive memory area (RW) = RW000 to RW127 Retentive memory area (T) = T000 to T031 Retentive memory area (C) = C000 to C031 Retentive memory area (D) = D0000 to D0511 Constant scan interval = 200 msec. Subprogram execution time limit = Not applicable (constant scan) Timer interrupt interval = 1000 msec. Station number = 1 Baud rate = 9600 bps Parity = Non Data bit length = 8 bits Stop bit length = 1 bit 6.13 Diagnostic Message Read (TR)

This command is used to read the user-defined diagnostic message. (the first registered message)



#### Response text



"CE" or "EE" is returned when communication error occurs

- When the Diagnostic display instruction (FUN 150) is executed in the PLC user program, user-defined error code and error message are registered in PLC internal table. This command read the first registered error code and error message from the table.
- Error code are expressed by hexadecimal format.
- If no error code has been registered, "0000" is returned as Error code. And in this case, the Error massage field (12 bytes) is not added.
- Refer to Section 6.5 PLC Status Read (ST) for contents of the Status field.

Execution examples Example 1)

INPUT DATA = (A01TR) SEND DATA = (A01TR&96) RECEIVE DATA = (A01TR00010000&17)

PLC status = H0001 (HALT) Error code = H0000 (no error code registered)

Example 2)

INPUT DATA = (A01TR) SEND DATA = (A01TR&96) RECEIVE DATA = (A01TR00020002LIMIT OVER &35)

PLC status = H0002 (RUN) Error code = H0002 Error message = LIMIT OVER Example 3)

## 6.14 Clock-calendar Read (RT)

This command is used read the PLC's built-in clock-calendar data.

RT)

Requ	est te	xt								
1	2	3	4	5	6	7	8	9	10	11
(	А	AD	DR	R	Т	&	SL	JM	)	CR
						←		$\rightarrow$		



## Response text

1	2	3	4	5	6	7	8	9	10		
(	А	AD	DR	R	Т	Status		itus			
	4.0	4.0			4.0		4.0	4.0			
11	12	13	14	15	16	17	18	19	20	21	22
Ye	Year		nth	Da	ay	Ho	bur	Mir	nute	Sec	ond

_	23	24	25	26	27
	&	รเ	JN	)	CR

"CE" or "EE" is returned when communication error occurs


- Clock-calendar data are expressed by 2 digits decimal format.
- Refer to Section 6.5 PLC Status Read (ST) for contents of the Status field.


## Execution examples Example 1)

INPUT DATA = (A01RT) SEND DATA = (A01RT&96) RECEIVE DATA = (A01RT0001911004155911&BC)

October, 4, 1991 15:59:11 PLC status = H0001 (HALT)

Clock-calendar Write (WT) This command is used to set the PLC's built-in clock-calendar data.





#### Response text

1	2	3	4	5	6	7	8	9	10
(	А	AD	DR	S	Т		Sta	itus	

11	12	13	14	15
&	SL	JM	)	CR

"CE" or "EE" is returned when communication error occurs

- Clock-calendar data are expressed by 2 digits decimal format.
- When the processing is completed normally, the PLC Status Read (ST) response is returned.

Execution examples Example 1)

INPUT DATA = (A01WT911005112049) SEND DATA = (A01WT911005112049&FC) RECEIVE DATA = (A01ST0001&58)


Normal complete --- October, 5, 1991 11:20:49

Example 2)

INPUT DATA = (A01WT911005251730) SEND DATA = (A01WT911005251730&FD) RECEIVE DATA = (A01EE0052&41)

PLC Error Response (Error 0052: Format error)

## 6.16 PLC Control (EC) This command is used to control the PLC operation mode.



#### Response text

1	2	3	4	5	6	7	8	9	10
(	А	AD	DR	S	Т		Sta	itus	

11	12	13	14	15
&	SL	JM	)	CR

"CE" or "EE" is returned when communication error occurs

- The Mode field of the request text specifies the PLC mode to be changed. (2 bytes)
- 01: HALT 02: RUN 03: RUN-F 04: HOLD 05: DEBUG 06: Error reset 07: HOLD reset
- The PLC status in the response text shows PLC mode after changed as par request.




(1) For detailed information of PLC mode, see your PLC's User's Manual.
(2) This command is not effective when the PLC operation mode switch is in HALT. (except Error reset)

# 6.Commands

Execution examples	Example 1)	
		<pre>= (A01EC02) = (A01EC02&amp;DA) = (A01ST0002&amp;59)</pre>
	Changing HALT t	o RUN - Normal complete
	Example 2)	
		<pre>= (A01EC04) = (A01EC04&amp;DC) = (A01ST0004&amp;5B)</pre>
	Changing RUN to	HOLD - Normal complete
	Example 3)	
		<pre>= (A01EC02) = (A01EC02&amp;DA) = (A01EE0114&amp;40)</pre>
	Command RUN during RUN mode - Mode mismatch (011	
	Example 4)	
	INPUT DATA SEND DATA RECEIVE DATA	
	PLC Error Status	Read - I/O mismatch (0041)
		<pre>= (A01EC06) = (A01EC06&amp;DE) = (A01ST0001&amp;58)</pre>
	Command Error reset - Normal complete	
	Example 5)	
		<pre>= (A01EC08) = (A01EC08&amp;E0) = (A01CE02&amp;DA)</pre>
	Format error (02)	Illegal code (08) was specified

System Information Block Read (BR) This command is used to read the system information from the PLC block-byblock. (Program up-loading)



"CE" or "EE" is returned when communication error occurs


- The PLC's system information memory contents are read by specifying the block number.
- The size of one block is 128 bytes.
- Block number is 0000 to 0015 (16 blocks). This command should be used from block 0000 through 0015 consecutively.
- The end code ";" (H3B) is used for block 0000 to 0014 to show a halfway block. And normal end code ")" (H29) is used for block 0015 to show the final block.

```
Execution examples
          Example 1)
          INPUT DATA = (A01BR0000)
          SEND DATA = (A01BR0000\&44)
          RECEIVE DATA =
          202020202020202020&D5;
          INPUT DATA
                = (A01BR0001)
          SEND DATA = (A01BR0001\&45)
          RECEIVE DATA =
          (A01BR00011C00FFFFFFFFFFFFFFF600000000120000801030089810000
          00000000000000000000&E2;
               •
               •
               .
                 = (A01BR0015)
          INPUT DATA
          SEND DATA
                 = (A01BR0015&4A)
          RECEIVE DATA =
          000000000000000000&4A)
```

The system information block read operation is completed normally.

## 6.18 Program Block Read (RB)

This command is used to read the user program contents from the PLC blockby-block. (Program up-loading)



"CE" or "EE" is returned when communication error occurs

- The PLC's user program memory contents are read by specifying the block number.
- The size of one block is 192 bytes.
- Block number is 0000 to 1007 (1008 blocks). This command should be started with block 0000 and in order.
- The end code ")" (H29) is returned if the block contains the program end. Otherwise, ";" (H3B) is returned.


Execution examples Example 1) R0000 -{ **+1** YW002}--1/†-Y0025  $\dashv \vdash$ -CNT ū R0001 -1/F-02048 COOO Y002F Y002E Y002D Y002C Y002B Y002A Y0029 Y0028 Y0027 Y0026 -1/---1/---1/---1/---**⊣**/<del>-</del> --↓⁄[---[ RST YW002]} -1/1--1/--1/F---1/1-R0002 -[00100 TON TO00]+[ C000 MOV YW004]+ -1/1-R0003 -[00100 TON T001]-[YW004 BCD YW003]--1/1-5 6-[END ]-

INPUT DATA = (A01RB0000)
SEND DATA = (A01RB0000&44)
RECEIVE DATA =
(A01RB00002C0000032200380008052B00080204300254F000181F000303
00083802F4C002E4C002D4C002C48002B48002A480029480028480027480
02640573000802043800281C00020364000502800800160804043800381C
008203640005BE00080404&2F;

The program block read operation is completed normally. (Number of blocks is 2)

## 6.19 Comment Block Read (CR)

This command is used to read the register/device comments (tags and comments) stored in PLC block-by-block. (Program up-loading)



"CE" or "EE" is returned when communication error occurs


- The PLC's comment memory contents are read by specifying the block number.
- The size of one block is 192 bytes.
- Block number is 0000 to 0991 (992 blocks maximum if 31 k steps are assigned for comments).
- The end code ")" (H29) is returned if the specified block is final. Otherwise, ";" (H3B) is returned.
- If no comment is stored in the specified block, the Block data field is not added in the response text.



The T1 and T2 series cannot store comments in it's memory. If this command is executed for the T1/T2, the Computer Link Error Response (CE) is returned.

```
Execution examples
            Example 1)
            INPUT DATA
                     = (A01CR0000)
                    = (A01CR0000\&45)
            SEND DATA
            RECEIVE DATA =
            0400000000040000000&85;
            INPUT DATA = (A01CR0001)
            SEND DATA
                    = (A01CR0001\&46)
            RECEIVE DATA =
            205B8B4E93AE835883438362836020202020202020200001000073773220
            205C92E28E7E835883438362836020202020202020200002000073773320
            205D8BD98B7D92E28E7E20&45;
            INPUT DATA = (A01CR0002)
            SEND DATA
                    = (A01CR0002\&47)
            RECEIVE DATA =
            (A01CR000220202020202020202020200003000073773420205E92CA8FED
            The comment block read operation is completed normally.
            (Number of blocks is 3)
            Example 2)
            INPUT DATA
                    = (A01CR0000)
            SEND DATA
                     = (A01CR0000\&45)
            RECEIVE DATA = (A01CE01\&D9)
            The Comment Block Read command (CR) is sent for T2. Command error (01)
```


System Information Block Write (BW) This command is used to write the system information data obtained by using the "BR" command into PLC memory block-by-block. (Program down-loading)



"CE" or "EE" is returned when communication error occurs

- The system information contents are written into PLC memory by specifying the block number.
- The size of one block is 128 bytes.
- Block number is 0000 to 0015 (16 blocks). This command should be used from block 0000 through 0015 consecutively.
- The end code ";" (H3B) must be used for block 0000 to 0014 to show a halfway block. And normal end code ")" (H29) must be used for block 0015 to show to the final block.

Program Block Write (WB) This command is used to write the user program data obtained by using the "RB" command into PLC memory block-by block. (Program down-loading)



"CE" or "EE" is returned when communication error occurs


- The user program contents are written into PLC memory by specifying the block number.
- The size of one block is 192 bytes.
- Block number is 0000 to 1007 (1008 blocks). This command should be started with block 0000 and in order,
- The end code ";" (H3B) must be used for halfway blocks. And normal end code ")" (H29) must be used for the final block.

## 6.22 Comment Block Write (CW)

This command is used to write the register/device comments (tags and comments) obtained by using the "CR" command into PLC memory block-byblock. (Program down-loading)

NOTE ▼∆▼

T3/T3H only



"CE" or "EE" is returned when communication error occurs

- The register/device comments are written into PLC memory by specifying the block number.
- The size of one block is 192 bytes.
- Block number is 0000 to 0991 (992 blocks maximum if 31 k steps are assigned for comments).

12

11 & 13

SUM

14

)

15

CR

- This command should be started with block 0000 and in order.
- The end code ";" (H3B)must be used for halfway blocks. And normal end code ")" (H29) must be used for the final block.



If this command is executed for the T1/T2, the Computer Link Error Response (CE) is returned.

## 7. Sample communication programs

This section provides four sample programs for the host computer. These programs have been written in IBM @ BASIC language. The transmission parameters have been set as 9600 baud, non party, 8 bits data length and 1 stop bit, in the sample programs.

7.1 Simple send/receive test The program can be used to test the communication between the PLC and the host computer.

```
110 '*
            COMPUTER LINK TEST 0
120 '*
             (SEND AND RECEIVE TEST)
160 SCREEN 0:KEY OFF:CLS
170 DEFINT A-Z
180 '********** COMMUNICATION INITIALIZE ********
190 OPEN "COM1:9600,N,8,1" AS #1
210 TEXT$="":DAT$=""
220 PRINT "INPUT DATA
                = ";
230 IF DAT$=CHR$(&HD) THEN 290
240
   DAT$=INKEY$:PRINT DAT$;
250
   TEXT$=TEXT$+DAT$
260 GOTO 230
270 '
290 PRINT "SEND DATA
               = ";
300 PRINT TEXT$;
310 PRINT #1, TEXT$;
330 RD$="":A$="":B$="":TIME$="00:00:00"
340 PRINT "RECEIVE DATA = ";
350 IF B=CHR(&HD) THEN 430
   IF TIME$="00:00:03" THEN PRINT "TIMEOUT ERROR":END
360
   IF LOC(1)=0 THEN 420
370
380
   A$=INPUT$(LOC(1),#1)
    RD$=RD$+A$
B$=RIGHT$(A$,1)
390
400
   GOTO 370
410
420 GOTO 350
430 PRINT RD$;
440 PRINT
450 GOTO 210
```

Send/receive test with sum check

The program can also be used to test the communication between the PLC and the host computer. The sum check routine has been added to the sample program described in Section 7.1.

110 '\* COMPUTER LINK TEST 1 120 '\* (SEND AND RECEIVE TEST) 160 SCREEN 0:KEY OFF:CLS 170 DEFINT A-Z 180 ON ERROR GOTO 700 190 '\*\*\*\*\*\*\*\*\*\* COMMUNICATION INITIALIZE \*\*\*\*\*\*\*\* 200 OPEN "COM1:9600,N,8,1" AS #1 220 TEXT\$="":DAT\$="":PRINT "INPUT DATA = "; 230 WHILE DAT\$<>CHR\$(&HD) DAT\$=INKEY\$:PRINT DAT\$; 240 250 TEXT\$=TEXT\$+DAT\$ 260 WEND 280 SUM=0:I=1 290 L=LEN(TEXT\$):IF L<=5 THEN PRINT "-- INPUT ERROR --":GOTO 220 300 SD\$=LEFT\$(TEXT\$,(L-2)):SD\$=SD\$+"&" 310 WHILE I<=1-1 A\$=MID\$(SD\$,I,1) 320 330 SUM=SUM+ASC(A\$) I=I+1 340 350 WEND 360 SUM\$=HEX\$(SUM) 370 SUM\$=RIGHT\$(("O"+SUM\$),2) 380 SD\$=SD\$+SUM\$+")"+CHR\$(&HD) 400 PRINT "SEND DATA = "; 410 PRINT SD\$; 420 PRINT #1,SD\$; 440 RD\$="":A\$="":B\$="":TIME\$="00:00:00" 450 PRINT "RECEIVE DATA = "; 460 WHILE B\$<> CHR\$(&HD) IF TIME\$="00:00:03" THEN PRINT "TIMEOUT ERROR":END 470 WHILE LOC(1)<>0 480 490 A\$=INPUT\$(LOC(1),#1) 500 RD\$=RD\$+A\$ 510 B\$=RIGHT\$(A\$,1) 520 WEND 530 WEND 540 PRINT RDS; 550 PRINT 570 SUM=0: I=1:A\$="" 580 L=LEN (RD\$) 590 WHILE A\$<>"&" 600 A\$=MID\$(RD\$,I,1) SUM=SUM+ASC(A\$) 610 620 I=I+1630 WEND 640 SUM\$=HEX(SUM) 650 SUM\$=RIGHT\$(("O"+SUM\$),2) 660 TESTSUM\$=LEFT\$(RIGHT\$(RD\$,4),2) 670 IF SUM\$<>TESTSUM\$ THEN PRINT "-- SUM ERROR --":END 680 GOTO 220 700 PRINT "ERROR ":CLOSE #1: RESUME 100

Program up-loading

This program can be used to read the user program (including the system information) from the PLC, and save it into a disk file.

1000	· * * * * * * * * * * * * * * * * * * *
1010	'* COMPUTER LINK TEST 2
1010	'* (BLOCK READ TEST)
1020	I ************************************
1040	'*************************************
1050	
1070	CLS:DEFINT A-Z
	BLK=0:B\$="":RD\$=""
1080	INPUT "SAVE FILE = ";NA\$
1090	OPEN NA\$ FOR OUTPUT AS #2
1110	'**** COMMUNICATION INTIALIZE ****
1120	OPEN "COM1:9600,N,8,1" AS #1
1140	'******* STATION NO SET ********
1150	INPUT "INPUT STATION NO ";A%
1160	STN%=A%+100
1170	IF STN% > 132 GOTO 1600
1180	STN\$=RIGHT\$(STR\$(STN%),2) '**********DATA SET***********
1200	
1210	B\$="":RD\$="":BL=BLK+10000
1220	BLK = RIGHT + (STR + (BL), 4)
1230 1240	SD\$="(A"+STN\$+"BR"+BLK\$+")"+CHR\$(&HD)
1240 1250	
1250	B\$="":RD\$"":BL=BLK+10000 BLK\$=RIGHT\$(STR\$(BL),4)
1200	SD\$="(A"+STN\$+"RB"+BLK\$+")"+CHR\$(&HD)
1290	5D5- (A +51N5+ KB +BLK5+ ) +CLK5(&HD)
1300	PRINT "SEND DATA = "SD\$
1310	PRINT #1,SD\$;
1330	'********DATA RECEIVE********
1340	RD\$="":BS="":TIME\$"00:00:00"
1350	PRINT "RECEIVE DATA = ";
1360	IF RIGHT\$(B\$,1)=CHR\$(&HD) THEN 1440
1370	IF TIME\$="00:00:03" THEN PRINT "TIMEOUT":BEEP:PRINT:GOTO 1610
1380	IF LOC (1)=0 THEN 1360
1390	B\$=INPUT\$(LOC(1),#1)
1400	RD\$=RD\$+B\$
1410	GOTO 1360
1430	'******* DATA SAVE *********
1440	PRINT RD\$
1450	IF LEN(RD\$)<>143 THEN GOTO 1500
1460	SV\$=MID\$(RD\$,11,128)
1470	WRITE #2,SV\$
1480	BLK=BLK+1
1490	IF RIGHT\$(RD\$,2)=CHR\$(&H29)+CHR\$(&HD) THEN BLK=0:GOTO 1250 ELSE 1210
1500	IF LEN(RD\$)<>207 GOTO 1580
1510	SV\$=MID\$(RD\$,11,192)
1520	WRITE #2,SV\$
1530	BLK=BLK+1
1540	IF RIGHT\$(RD\$,2)=CHR\$(&H29)+CHR\$(&HD) GOTO 1580
1550	GOTO 1250
1570	'*******COMPLETE*********
1580	CLOSE:PRINT "COMPLETE":GOTO 1630
1590	END
1600	PRINT "STATION NO ERROR"
1610	INPUT "RETRY Y/N ";A\$
1620	IF A\$="Y" GOTO 1140 ELSE END
1630	INPUT "TEST CONTINUE Y/N";A\$
1640	IF A\$="Y" GOTO 1650 ELSE END
1650	CLOSE COM1:GOTO 1060

Program down-loading


This program can be used to load the user program (including the system information) into the PLC. (Disk file  $\rightarrow$  PLC)

1000 '\* COMPUTER LINK TEST 3 1010 1020 ۰ \* (BLOCK WRITE TEST) 1040 1050 CLS:DEFINT A-Z:B\$="":BLK=0 1060 1070 INPUT "LOAD FILE =";NA\$ 1080 ON ERROR GOTO 1650 1090 OPEN NA\$ FOR INPUT AS #2 1110 '\*\*\*\* COMMUNICATION INTIALIZE \*\*\*\* OPEN "COM1:9600,N,8,1" AS #1 1120 '\*\*\*\*\*\*\*\* STN NO SET \*\*\*\*\*\*\*\*\* 1140 INPUT "INPUT STATION NO 1150 ";A% 1160 STN%=A%+100 1170 IF STN% > 132 GOTO 1580 1180 STN\$=RIGHT\$(STR\$(STN%),2) '\*\*\*\*\*\* INF BLK DATA LOAD \*\*\*\*\*\* 1200 1210 IF BLK=16 THEN BLK=0:GOTO 1310 IF BLK=15 THEN ED\$=CHR\$(&H29) ELESE ED\$=CHR\$(&H3B) 1220 1230 PRINT: INPUT #2,LD\$ 1250 '\*\*\*\*\*\* INF BLK DATA SEND \*\*\*\*\*\* 1260 BL=BLK+10000: BLK=BLK+1 1270 BLK\$=RIGHT\$(STR\$(BL),4) 1280 SD\$="(A"+STN\$+"BW"+BLK\$+LD\$+ED\$+CHR\$(&HD):GOTO 1370 '\*\*\*\*\* PROGRAM BLK DATA LOAD \*\*\*\*\* 1300 PRINT: INPUT #2,LD\$ 1310 IF EOF(2) THEN ED\$=CHR\$(&H29) ELESE ED\$=CHR\$(&H3B) 1320 1340 '\*\*\*\*\* PROGRAM BLK DATA SEND \*\*\*\* 1350  $BI_{H} = BI_{K} + 10000 : BI_{K} = BI_{K} + 1 : BI_{K} \leq BT_{G} + T \leq (STR \leq (BI_{L}), 4)$ 1360 SD\$="(A"+STN\$+"WB"+BLK\$+LD\$+ED\$+CHR\$(&HD) 1370 PRINT "SEND DATA = "; PRINT SD\$; 1380 PRINT #1,SD\$; 1390 '\*\*\*\*\*\*\*\* DATA RECEIVE \*\*\*\*\*\*\*\*\* 1410 B\$="":TIME\$="00:00:00" 1420 PRINT "RECEIVE DATA 1430 = "; 1440 B\$=RIGHT\$(B\$,1) 1450 IF B\$=CHR\$(&HD) THEN 1500 IF TIME\$="00:00:03" THEN PRINT "TIMEOUT ERROR":BEEP:PRINT:GOTO 1610 1460 1470 IF LOC(1)=0 THEN 1440 1480 B\$=INPUT\$(LOC(1),#1) 1490 PRINT B\$;:GOTO 1440 1500 CMD\$=MID\$(SD\$,5,1) 1510 IF CMD\$=CHR\$(&H42) THEN GOTO 1200 1520 IF RIGHT\$(SD\$,2)=CHR\$(&H29)+CHR\$(&HD) AND CMD\$=CHR\$(&H57) GOTO 1550 1530 GOTO 1310 1550 '\*\*\*\*\*\*\*\*\*\* COMPLETE \*\*\*\*\*\*\*\*\*\* 1560 CLOSE:PRINT:PRINT"COMPLETE":GOTO 1590 1570 END 1580 PRINT "STATION NO ERROR" INPUT "TEST CONTINUE Y/N ";A\$ 1590 IF A\$="Y" THEN BLK=0:GOTO 1640 ELSE END 1600 INPUT "RETRY Y/N";A\$ 1610 1620 IF A\$="N" THEN END 1630 CLOSE COM1:OPEN NA\$ FOR INPUT AS #2:BLK=0:GOTO 1110 1640 CLOSE COM1:GOTO 1050 1650 PRINT "NO SEARCH FILE" :GOTO 1590

## A.1 Transmission specifications

Item	Specifications
Interface	Conforms to RS485 (connector D-sub 15p)
Transmission mode	Half-duplex,4-wire method
Signal polarity	PXA < RXB, TXA < TXB (potential of start bit)
Synchronizing	Start-Stop (asynchronous)
Topology	Bus (multi-drop)
Transmission speed	300, 1200, 2400, 4800, 9600, or 19200 bps (selected by T-PDS)
Transmission distance	1km maximum
Transmission code	ASCII
Data length	7 or 8 bits (selected by T-PDS)
Stop bit	1 or 2 bits (selected by T-PDS)
parity	Non, odd, or even (selected by T-PDS)
Number of stations	32 stations maximum
Error check	Parity, check-sum

Connector pin assignment



Pin No.	Signal name
1	FG
2	RXA
3	TXA
4	CTSA
5	RTSA
7	SG
10	RXB
11	ТХВ
12	CTSB
13	RTSB



The female connector is provided on the front panel of PLC's CPU module.

## A.2

RS485/RS232C converter The specifications of the RS485/RS232C converter are as follows.

## Model: ADP-6237B (part number: EX25PADP6237B)


General specifications:

Item	Specifications
Power supply voltage	85 to 132/170 to 264 vac (50/60 Hz)
Power consumption	15 VA or less
Operating temperature	0 to 55 °C
Storage temperature	-20 to 75 °C
Humidity	20 to 90%RH
Withstand voltage	1500 Vac for 1minute

Transmission specifications:

	Item	Specifications
RS232C side	Interface	Conforms to RS232C (connector D-sub 25p)
	Transmission distance	15 m maximum
RS485	Interface	Conforms to RS485 (terminal block)
side	Transmission distance	1km maximum
	Number of stations	32 stations maximum

RS232C connector pin assignment:




Pin No.	Signal name
1	FG
2	TXD
3	RXD
4	RTS
5	CTS
6	DSR
7	SG
8	CD
20	DTR




The female connector is provided on the converter.

External feature: [mm]



LEDs	Condition
TXD	Lit when TXD is mark state
RXD	Lit when RXD is mark state
ENB	Lit when CTS is mark state
POWER	Lit when power supply is normal



# TOSHIBA

## **TOSHIBA CORPORATION** Industrial Equipment Department

1-1, Shibaura 1-chome, Minato-ku Tokyo 105-8001, JAPAN Tel: 03-3457-4900 Fax: 03-5444-9268